Cording

Machine Settings:







Foot: Cording Foot H Foot Pressure: 3 Needle Thread: All-Purpose Thread Bobbin Thread: All-Purpose Thread Cord: Pearl Cotton, Knitting Yarn, Embroidery Floss, Lace Thread, Fine Wool, Lily Yarn, etc.

- Mark the design on the right side of fabric. Draw the sewing threads to the left and under the foot. Insert the cord(s) under the spring of the foot and draw under the foot to the rear Tips:
 - *Up to three lengths of cord may be used depending on your design.

*When sewing a single length of cord, select the Zigzag stitch, set the width to 3.0 and use the center groove on the foot.

- 2. Draw 10 cm (4") of cording behind the foot. The slots and bottom grooves on the foot will hold the length(s) of cord in place while stitching.
- 3. Hold multiple cords parallel for even sewing and be sure to match the stitches over the strands. Start sewing slowly and smoothly, turning the fabric as you sew to guide the cords over the marked line.